

## Fiber Dispenser For Mobile Concrete Plants

### *Fiber bobbins installation*



Open the box



Get the bobbin out of the box



Pull all the mixed strands out of the bobbin until the inside looks well winded.



Do not pull out the strand which comes out of the wrap (which is tied with the strand coming out of the inside of the bobbin). Just cut it.



Cut also the strand coming out of the inside to separate it from the mixed strands.



And hide the strand coming out of the wrap under the wrap



We get now one strand coming out of a "clean" bobbin




Make pass the strand through the hole from the top to the bottom up to the cutting system. Make sure every single fiber of the strand is introduced in the same hole among the 3 which are available.



Place the bobbin



Hold it a little bit while chopping the strand in excess



The system is now ready to work!

**VM FIBER FEEDER, Inc.**  
7850 Fruitville Road  
Sarasota, Florida 34240, USA

**Tel: +1 941 342 9997**  
**Fax: +1 941 342 1771**  
**[www.vmfiberfeeder.com](http://www.vmfiberfeeder.com)**  
**[info@vmfiberfeeder.com](mailto:info@vmfiberfeeder.com)**



## INTRO Fiber Dispenser

Proper assembly of cutter unit



Please note: Cutter Head must be installed so that **Blue Dot faces out**, as shown.



## INTRO Fiber Dispenser



Please note the proper orientation of cutter head **spacer** (shown with cutter wheel removed).